



ATtiny Pin 2 to Arduino Pin 13 (for SCK of another programmer)
 ATtiny Pin 3 to Arduino Pin 12 (for MOSI of another programmer)
 ATtiny Pin 8 to Arduino Pin 14 (for MISO of another programmer)
 ATtiny Reset Pin to Arduino Pin 10 (for RESET of another programmer)

