
+12V
6.8k
R24
GND
1k
R26
100n
C8
U2
DIVIDEG$2
D6-ILLUM
R19
1k
DIVIDE-OUT
DIVIDE
PULSE
R1
100k
R18
100k
VCC
1IN-
1IN+
2IN+
2IN-
GND
1OUT
2OUT
LM358
R21
1k
PULSE-OUT
J1
MISO
SCK
RESET
+5
MOSI
ISPTOUCH_HEADER
6.8k
R29
1k
R30
PULSEG$2
D6-ILLUM
U1
+5V
100n
C5
PB0
PB1
PB2
PB3
PB4
PB5
R31
2k
ODD_LED
DIVIDEG$1
D6-ILLUM
PULSEG$1
D6-ILLUM
ATTINY85
ATtiny Pin 2 to Arduino Pin 13 (or SCK of another programmer)
ATtiny Pin 1 to Arduino Pin 12 (or MISO of another programmer)
ATtiny Pin 0 to Arduino Pin 11 (or MOSI of another programmer)
ATtiny Reset Pin to Arduino Pin 10 (or RESET of another programmer)
LEFT_TOP
LEFT_MID
82k
R12
18k
R13
130k
R14
30k
R15
RIGHT/Mono
LEFT
82k
R10
R11
18k
130k
R16
30k
R17
0db
-4db
-8db
R25
200k
R20
200k
R22
1k
1k
R23
RIGHT_TOP
RIGHT_MID
RIGHT_LOW
LINE_IN
THONKI-STEREO
100k
150k
400k
1k - more sensitive
line input
+12V
C1
100n
C2
100n
-12V
IC2B
NE5532
R27
10k
IC2A
NE5532
R28
10k
VOLUMES$1
100k Audio
VOLUMES$2
100k Audio
IC1A
IC1B
C7
22µ
100n
C3
100n
C6
R5
2k
R4
2k
R9
2k
R8
2k
47R
R6
47R
R7
RIGHT
LEFT
THONKI-STEREO
HP-OUT1
THONKI-STEREO
HP-OUT2
+12v
5819
D3
D4
5819
SV1
EURO_POWER_HEADERREGULAR
-12v
U$4
VIN
VOUT
GND
MCP1703
1uf
C11
1uf
C10